


# Installation, Operation & Maintenance Manual

Plate and Frame Heat  
Exchangers



**IMPORTANT!** - READ ALL INSTRUCTIONS IN THIS MANUAL  
BEFORE OPERATING OR SERVICING A PUMP.

**→NAMEPLATE FOR FLOFAB HEAT EXCHANGER**

The nameplate gives important information about the design of the heat exchanger. This information is related to the design and approval of the heat exchanger. The values on the nameplate may not be exceeded.

This plate is fitted on the plate heat exchanger and provides information about:

- Heat exchanger type
- Manufacture number
- Allowable pressures
- Test pressures
- Allowable temperatures
- Volume
- Year of construction
- Tensioning dimensions
- Differential pressure

Each heat exchanger is delivered with a dimension drawing and a circuit diagram.

- The dimension drawing includes outer dimensions as well as the type, size and position of the piping connections.
- The circuit diagram shows the specific arrangement of the plates, their type, alloyed steel, thickness and gasket material.

**→CORRECT OPERATION**

This instructional manual provides the necessary information for correct and safe operation to avoid accidents or incorrect use. Always follow the instructions and safety regulations.

If a problem occurs with your heat exchanger, please contact a FloFab representative – all indistinctions must be solved to avoid injuries and damages. FloFab will not accept responsibility for any damage or injury resulting from not following the instructions in this manual.

FloFab heat exchangers are specifically designed and built for the operating conditions, therefore sudden changes should be prevented, as they can severely damage the heat exchanger. The heat exchanger should be used in accordance with the specified configuration of material, media types, temperatures and pressure for your specific customized heat exchanger.

**FLOFAB**  
SINCE 1981

**SERIAL NUMBER**

TYPE:  YEAR:

MANUFACTURER NO.:  MARKING:

ASSEMBLING MEASURE MIN.:  INCHES:

MAX. DIFFERENTIAL PRESSURE:  PSI:

PS. MAX WORKING PRESSURE PSI:	PRODUCT/MEDIUM: <input type="text"/>	PT. MAX TEST PRESSURE PSI:	PRODUCT/MEDIUM: <input type="text"/>
-------------------------------	--------------------------------------	----------------------------	--------------------------------------

FLUID:  V. VOLUMEN GPM:

TS. MIN WORKING TEMPERATURE °F:  TS. MAX WORKING TEMPERATURE °F:

**IMPORTANT:**

- 1) The Plate heat exchanger must not be assembled under the stated minimum assembling measure. Please contact SonFlow distributor if the plate heat exchanger is leaking when tightened to the minimum measurement.
- 2) The starting up must be done without shocks and against closed valves.

If you wish to modify the design conditions, please contact a SonFlow representative – written approval by SonFlow are necessary. Always consult a SonFlow representative for advice on:

- New plate pack dimensions if you intend to change the thermal tasks
- Selection of gasket material if operating temperatures and pressures are permanently changed, or if another medium is to be processed in the heat exchanger.

**→ PRECAUTIONS**

Please be aware of bodily injury and equipment damage.

**Bodily injury:**

- Burns as a result of touching the heat exchanger
- Release of pressurized media application
- Contact with chemicals
- Sharp edges

**Damage to equipment:**

- External forces
- Corrosion
- Chemical action
- Erosion
- Material exhaustion
- Water hammer (can appear during the start-up/shut down of a system or an off/on valve)
- Thermal/mechanical shock
- Freezing
- Transportation/lifting

The heat exchanger may only be used with the fluids specified on the nameplate and design sheets.

**Start-up:**

- Check the bolts are tight enough as they can loosen during transport.
- Check that there are no visible leakages from the plate pack, valves or piping system. A demountable heat exchanger can always leak, therefore, consider installing a drip tray underneath the heat exchanger.

If the heat exchanger's temperature is below the gasket's minimum temperature before installation and service, we recommend heating the heat exchanger above this limit to avoid cold leakage and deformed plates. Before pressurizing the heat exchanger, it is important to ensure that the temperature of the heat exchanger is within the temperature range as stated in the dimension drawing.

If the heat exchanger is shut down for several days or longer, it should be drained. Draining should also be done when the process is shut down and the ambient temperature is below the freezing temperature of the media. Depending on the media processed, it is recommended to rinse and dry the heat exchanger plates and connections (described in section 4.2).


**→ THERMAL DESIGN**

FloFab plate heat exchangers are designed and calculated according to the newest technology. In the design sheet, the nominal capacity and pressure losses are mentioned. If a performance test must be carried out, the exchanger must be clean.


The basic structure of a heat exchanger is shown below.  
The specific execution depends on the application.

**Figure 1 Main components**

- 1 - Frame plate
- 2 - Pressure plate
- 3 - Carrying bar
- 4 - Guiding bar
- 5 - Support column
- 6 - Plate pack
- 7 - Tightening bolts



Main components of a gasketed heat exchanger, industrial design.



**→ FRAME**

The heat exchanger consists of a frame plate (head), a pressure plate (moveable), a carrying bar, a guiding bar and a column. The tightening bolts are used to press the plate package together. The size and number depend on the heat exchanger type. There are different designs of the frame depending on the design pressure and the application of the heat exchanger.

Basic version of FloFab frames, which are available in various application specific versions.

**→ PLATES**

The number of plates is, as well as size and dimension, depending on the thermal output and flow rate required. The type of material depends on the media and their temperatures; please check the design sheet when ordering spare parts.

The plates can be made of a variety of materials, compatible with the process.

**The material used:**

- Stainless steel
- Titanium
- Nickel
- C276
- SMO254
- Other materials on request

**→ GASKETS**

The gaskets prevent intermixing of the media and can be supplied in different materials such as NBR, EPDM and Viton. The gasket material is specifically selected to be compatible with the medium processed. The click-on gasket is a "glueless" system for sealing - the gaskets are a single piece, molded construction, which fits into the continuous gasket groove in each plate. The "glueless" system is an easy and fast click-on installation without any glue or tools. The gasket is also simple to remove.



**Replacement of old gaskets:**

- Remove the plate from the frame
- Slowly pull the gasket away
- Clean and dry the gasket groove
- Position the new gasket on the plate for a proper groove fit
- Make sure that the tabs of the gasket are lined up with the slots
- Insert each tab inside its corresponding slot and push firmly until the tab locks into the slot

**→ PLATE TYPES**

The plate material is selected accordingly to the customer's requirements (e.g. pressure, temperature, media, operating mode).

The plates are available in several different designs:


- A herringbone pattern, to optimize performance, comes in a thermal short (TK) and a thermal long (TL) model, which can be mixed into a third variation - thermal mix (TM).
- A Free Flow model with wide channels suitable for difficult media containing solids or high viscous products.

All types of plates are designed to create the best possible heat transfer:



Thermal short plate: short wide chevrons.

Provides a lower heat transfer and pressure drop



Thermal long plate: tall skinny chevrons.

Provides a higher heat transfer and pressure drop



Free Flow plate: wide channels, ideally suited for fibres, particles and high viscous products.


**→ STARTPLATE**

Replace the start gaskets using two standard gaskets:

1. Cut two gaskets into half, and cut away the hang-on tab and the pieces between the rings. Discard the half without rings.
2. Apply a small amount of glue onto the gasket groove, on the marked area. (We recommend: Superglue klebfix 4-in-1 from Würth) Be sure to apply glue only to the outside of the gasket groove at the porthole area. If glue reaches the inside of the porthole, the start plate can leak.
3. Apply the two gasket halves with rings in the gasket track.

**→ PLATE FUNCTION**

The heat exchanger consists of a pack of corrugated metal plates with port holes for the inlet and outlet of the two separate mediums. The heat transfer takes place through the plates. The plates are fitted with a gasket that seals the channel and directs the fluids into alternate channels. The plate corrugation promotes fluid turbulence and supports the plates against differential pressure.



1) Cut two gaskets into half, and cut away the marked tabs.

2) Apply a small amount of glue on the green marked area. If glue reaches the red marked area the start plate can leak.

3) Apply the two gasket halves in the gasket track.

Our heat exchangers are designed for either single-pass or multi-pass flow, depending on the duty. Single-pass is the preferred solution; as it keeps all connections on the head part, which makes installation cheaper and service easier.


Multi-pass is required when the temperature differences between the flow medium are small. In this case, the connecting piping is on the fixed plate and on the moveable plate.

**→FLOW ARRANGEMENT**

The heat transfer plates with gaskets are arranged in an alternating pattern, of left-hand flow and right-hand flow, to direct the fluids in an opposing direction within the heat exchanger.

The FloFab plates are designed to be used as both right and left plates by rotating the plates 180°. Every plate can be recognized by the plate charge number and thermal short or thermal long execution.

When the plate package is pressed together, the portholes form continuous tunnels, leading the media, from the inlets into the plate package, where the media is distributed into the narrow passages between the plates.




Due to the gasket arrangement on the plates, the two liquids enter alternate passages separated by a thin metal wall.

**→PRESSURE DROP**


Some pressure drop is unavoidable, however, it should be kept as close as possible to the designed value. A reduced ability to hold the desired temperatures, in combination with increased pressure on the media, indicates fouling or clogging.

**→HEAT TRANSFER PROBLEMS**

Measure the flow rates and temperatures on both mediums, and check if the amount of heat energy corresponds to the specifications. If the capacity of equipment has dropped below the specified values, the heat exchanger must be inspected and cleaned.



Example of a single-pass set up



Example of a multi-pass set up

**→REMOVAL OF PLATES**



Exercise care when handling plates and use protective gloves.



Never open a heat exchanger until the unit has cooled below 40 °C. Never open a heat exchanger, which is under pressure from any source. Never open a heat exchanger without dismantling the piping first.

**Opening procedure:**

- Shut down the heat exchanger
- Close the valves
- Drain the heat exchanger
- Dismantle pipes from the pressure plate
- Inspect the sliding surfaces of the carrying bar
- Mark the plate assembly on the outside by a diagonal line
- Measure and note the dimension
- Remove the locking bolts
- Use the tightening bolts to open the heat exchanger
- Remove the plates one by one, by tilting backwards and then sideways of the carrying bar
- Clean and inspect the plates

**→REPLACING PLATES**


A plate can easily be removed and replaced by a spare plate. When the plates are properly assembled, the edges form a “honeycomb” configuration.

**→CLEANING OF PLATES**

The FloFab plates are designed for manual cleaning and cleaning-in-place (CIP) operations. Before disassembly, the user must assure that the unit has been locked out, de-pressurized, at ambient temperature and drained.

Manual cleaning is normally accomplished by washing the plates with a soft non-metal brush, water and cleaning solution. It is recommended to lay the plate on a flat surface during brush cleaning to avoid the risk of bending the plate.

If the heat exchanger is heavily fouled, care must be taken to remove all debris from the gasket sealing surfaces when the heat exchanger is reassembled.



**Manual cleaning of plates:**

1. Open the unit (described in section 2.9)
2. Clean each plate separately
3. Never use a steel brush or steel wool
4. Do not scratch the gasket surfaces
5. Rinse each plate with clean water (free from salt, Sulphur, chlorine, or high iron concentration)
6. Use high pressure rinse
7. Wipe the gaskets clean or replace it
8. Wipe off the mating surface
9. Inspection and installation of each plate
10. Close the unit



**CIP-cleaning (cleaning in place):**

A CIP system allows cleaning of the unit without disassembling, which is quick, easy and cost effective. The cleaning is accomplished by circulating a suitable cleaning solution through the heat exchanger instead of opening it. The chemicals used for cleaning must be compatible with materials of construction, while the cleaning solution must be able to dissolve the fouling on the plates.

**Cleaning-in-place (CIP):**

1. Drain both sides of the unit
2. Flush the unit on both sides with warm water
3. Drain the flush water from the unit and connect CIP pump
4. Rinse with warm water or warm water with softener at maximum flow rate - achieve the best cleaning in the reverse direction of normal flow
5. Flush thoroughly with clean water after CIP cleaning

**CAUTION**

Do not use chlorine or chlorinated water to clean stainless steel. Do not use phosphoric or sulfamic acid for cleaning titanium plates.

**Qualified cleaning chemicals:**

- Remove oil and grease with a water emulsifying oil solvent
- Remove organic and grease cover with sodium hydroxide (NaOH) maximum concentration 1.5 % - maximum temperature 85 °C. concentration = 5.00 ltr. (30 % NaOH) per 100 ltr. water.
- Remove stone and limestone with nitric acid (HNO<sub>3</sub>) - maximum concentration 1.5 % - maximum temperature 65 °C. 1.5 % concentration = 2.4 ltr. (62 % HNO<sub>3</sub>) per 100 ltr. water.
- Nitric acid also has an effective build-up effect on the passivation film of stainless steel.





Plate assembly



Always place the heat exchanger on a solid foundation floor. Enough space around the unit (1.5m from the walls), is mandatory when maintaining, renewing plates or tightening the plate package. The authorized personnel are always responsible for the safety, correct selection of lifting equipment and execution of the lifting.

### → LIFTING

The heat exchanger is supplied horizontally on a pallet, with the back of the head tightened. The heat exchanger can be transported by a forklift.

**NOTE: Be careful as the forklift can damage the heat exchanger.**

**If the weight of the heat exchanger exceeds 3000 kg this option is not available.**

Only use straps approved for the weight of the heat exchanger.

FloFab heat exchangers are provided with holes for safe lifting and transportation. Always observe proper procedures for lifting and/or moving equipment.

When lifting an assembled heat exchanger frame, ensure that the lifting point is above the centre of gravity of the equipment. The angle should not exceed 120°C at any time.

### ⚠ WARNING

To prevent personal injury, use suitable lifting gear. If you need to lift the heat exchanger, use straps placed as shown in the drawing.

### Carefully follow the instructions below:

- Remove all tightening elements from the pallet
- Place straps around one bolt on each side (never use steel cables or chains!)
- Lift the heat exchanger
- Lower the heat exchanger slowly to vertical
- Remove the straps and tighten the unit to the floor

### ⚠ REMEMBER

- Use the lifting eyes (when lifted)
- Lift the top side
- Attach the straps to the bolts by the head

### ⚠ NEVER

- Lift by the connections
- Lift the moveable plate
- Lift with a strap attached to the moveable plate

### → RAISING

This instruction is valid when raising the heat exchanger after delivery from FloFab. Only use straps approved for the weight of the heat exchanger. The straps shall be long enough for the heat exchanger to rotate.

Follow the principles:


1

Remove the support feet and place two timber beams on the floor



4

Place straps around the heat exchanger



2

Lift the heat exchanger off the pallet by using straps



5

Lift the heat exchanger from the timber beams



3

Place the heat exchanger on the timber beams



6

Lower the heat exchanger to horizontal and place it on the floor



**→ CONNECTIONS**

If the heat exchanger has connections on the moveable plate, the compressed dimension must be checked against the drawing before the pipes are connected. It is necessary to leave free space around the equipment to give access and make future service possible. The dimensions suggested are 1.5 m to provide reasonably good working conditions during installation as well as maintenance and service.

**→ INSTALLING THE PIPE CONNECTIONS**

Flanges, couplings, threaded pipes etc. will be equipped according to the type of FloFab heat exchanger.

**Our advice:**

- Support the heavy pipework, that will prevent heavy forces on the heat exchanger
- To prevent vibrations always install flexible connections on the moveable plate, which also will prevent the expansion of the pipework caused by temperature influence – must be fitted in a longitudinal direction to the plate package
- Before connecting to the heat exchanger, always remember to thoroughly clean the pipework
- Vents must be installed on both sides of the heat exchanger

**NOTE**

Vents should be fitted on the highest point in the direction of the flow of the medium. Shut off valves in all connections when opening the heat exchanger.

**Threaded pipe connections**

If a threaded pipe connection is provided, connections may not rotate when fitting to the pipework, as it could damage the gasket on the start plate.

**Flange connections**

If the connection is rubber lined, the liner will act as the flange gasket. The connecting flange must be bolted directly to the endplate by using the drilled and tapped holes. Bolts must be tightened evenly (do not overtighten!).

Unless otherwise stated, the liquid circuits should be connected to flow in reverse directions through the exchanger (counter-current).

**→ STORAGE**

Certain precautions are necessary when storing the heat exchanger for a longer period (1 month or more). The heat exchanger should be stored indoors with a temperature of 15 to 20 °C and humidity of max. 70 %.

The heat exchanger can also be stored in a wooden box provided with a lining on the side against penetration of moisture. It must be protected from water, debris and sunlight, while also allowing air circulation.

Ozone producing equipment in the storage room is prohibited due to the destruction of rubber materials, such as operating electric motors or welding equipment. Do not store organic solvents or acids in the room and avoid heat or ultraviolet radiation.

All connections must be closed to prevent water or debris to enter the heat exchanger. Plugs or covers may be used.

**→ START-UP**

Before start-up, check that all tightening bolts are firmly tightened and the plate pack has correct measurements.

Starting-up the heat exchanger must be initiated slowly and smoothly to avoid any pressure shocks/water hammering which might damage the equipment or cause leakage:

- Make sure the plate pack is compressed to the right measurements 16
- Avoid extreme variations of temperature and pressure to avoid damages
- Before starting any pump, check instructions and check the valve between the pump and the equipment controlling the flow rate of the system
- The valve at the exit should be fully open – if there is one
- Open the vent
- Start the pump
- Open the valve slowly
- When all air is out, close the vent
- Repeat the procedure for the other media
- Design pressures and temperatures for each model are marked on the nameplate, which shall not be exceeded

Take protective actions to avoid risk for material and personnel injuries. Always ensure that the required actions are according to local regulations.

Commissioning may only be executed by trained staff or by FloFab commissioning engineers.

Maintenance, repair and control of the unit may only be executed by authorized and trained staff.

Maintenance and cleaning may only be executed when the temperature of the heat exchanger is below 40°C and shut down.



If you use hazardous flow media (e.g. explosive, flammable, caustic, toxic, under high pressure, very hot or very cold) persons can get in contact with the flow medium and become injured if the heat exchanger is leaky.

### Before starting the heat exchanger commissioning, follow the conditions below:

- That all components have been completely installed
- All piping connections are firmly connected
- Tensioning dimension of the heat exchanger pack is within the permitted value range
- That no residues are present inside the heat exchanger

### Operating conditions:

- Avoid liquid hammers
- Make sure that the heat exchanger is not operated with unpermitted flow media, pressure or temperature levels
- Ensure that the heat exchanger is vented

### Filtration

Filtration prevents foreign particles with a potential risk of disrupting the performance of the system. The filter prevents particles from flowing through the heat exchanger and cause clogging of the heat exchanger.

### → OPERATION

Always start with the cold circuit, afterwards the hot circuit.

### Fully vent the system:

- Close and shut off the valve fitted between the pump and exchanger
- Fully open the valve fitted into the return line from the exchanger
- Start the circulation of the pump normally when placed by the inlet
- Gradually open the closed and shut off valve between the pump and exchanger

- Vent system again if necessary

Repeat the above for the secondary circuit.

### Steam as the media

Slowly use acting steam control valves and slowly open the shut-off valves.

### Before starting:

- Ensure that the steam control valve is fully closed
- Ensure that the heat exchanger is fully drained of condensate
- Start cold circuit first, then the steam
- Slowly open the steam control valve – prevents thermal shock to the exchanger
- Ensure that the steam trap is correctly sized to allow condensate discharge, which prevents water from clogging

### Check for proper operation:

- Check for pressure pulses in the system caused by the pumps or control valves. Stop operation and rectify if found
- Check the unit for leakages
- Check that all the vents are closed to prevent air from being sucked inside.

### → SHUT DOWN FOR A SHORT PERIOD

Follow the following procedure:

- Close the control valve in the hot circuit and maintain the full flow in the cold circuit
- Turn off the hot circuit pump
- The heat exchanger must cool down
- Close the control valve in the cold circuit
- Turn off the cold circuit pump
- Close all remaining shut off valves

### → SHUT DOWN FOR A LONG PERIOD

If the unit must be disconnected, follow the following procedures:

- Never open a heat exchanger unit when it is hot the heat exchanger must cool down
- Decrease the pressure of both fluids
- Completely drain fluids from the unit
- Lubricate all bolts
- Loosen the clamping bolts until the plate pack is loosened
- Do not remove tie bolts
- Cover the plate pack to avoid sunlight



Never open a heat exchanger until the unit has cooled below 40 °C.  
Never open a heat exchanger, which is under pressure from any source.  
Never open a heat exchanger without dismantling the piping first.

FloFab recommends maintenance once a year as a minimum to keep the heat exchanger in good condition.

The plates must be cleaned regularly depending on the type of media and temperature. After a long period of use, it can be required to regasket the heat exchanger.

### What should be performed regularly:

- Lubricate the carrying bar and guiding bar
- Lubricate bolts
- Check temperatures and flows
- Check general condition
- Look for signs of leakage
- Look for signs of damage
- Check bolts and bars for rust

For large units, block the moveable plate into position, by tying it to the end support, to provide extra safety against accidental rolling of the moveable plate during maintenance.



Always wear protective gloves when handling plates.

### →FRAME MAINTENANCE

#### Carry out simple maintenance work of the frame:

- Clean the outside of the heat exchanger frame, especially the beams, rails and bars
- Grease the guide rails
- Rework paint damage

### →PRESSURE TEST AFTER MAINTENANCE

These processes are only allowed to be performed by a person authorized according to local laws and regulations and following applicable standards.

It is recommended to perform a pressure test to confirm the internal and external sealing function of the heat exchanger.

Test pressure is stated on the nameplate - the pressure test shall be performed at equal pressure, never above the design pressure.

In a multi-section setup, all sections of the same side must be tested simultaneously.

Test time: 10 minutes

If the unit is leaking, it may be tightened step by step according to the dimensions, which are mentioned on the nameplate.

Rebuilding or modification of the heat exchanger is the responsibility of the end-user.

### → PROBLEM SOLVING

In most cases, problems can be solved by your own personnel when it comes to:

#### Leakage:

- At the connections – check the rubber liners, check the flange gasket, check the O-ring and fit the pipes tension-free
- Mixing of a primary and secondary circuit – check the plates for holes and cracks
- Plate package – check the assembly, check the condition of the gaskets, check the proper position of the gasket
- Tighten the plate package step by step according to the dimensions, which are mentioned on the nameplate
- The operating conditions – adjust the operating conditions

#### Insufficient capacity:

- Air in the system – de-aerate the pipe system and check the pipework for possible air traps
- Conditions deviate from the specification – adjust the operating conditions
- A dirty heat exchanger – clean the heat exchanger
- Connections have been interchanged – do the pipework again

#### Too high-pressure drops:

- Flow larger than the design flow – adjust the flow
- Channels blocked in the plates – flush/clean
- Incorrect measurements – check the pressure indicator
- Medium deviating from the design – anti-freeze will increase the pressure drop
- Air in the system – de-aerate the pipe system and check the pipework for possible air traps

### → AFTER-SALES & SERVICE

When ordering parts, the following should be quoted:

- Exchanger type and manufacturing number
- Required parts
- Plate types
- Gasket material

We are globally active, therefore, not far away to support you and obtain the maximum availability of your systems. We aim to ensure high-quality spare parts for the trouble-free operation of your heat exchanger. We are always happy to answer any questions you may have and meet your requirements. We look forward to hearing from you.

